



LSL245C

Maintenance Plan (Not USA)

excel esprit esprit turbo

Owner's name Date

Registration No. Job no.

V.I.N. Mileage

Mark as follows:

Adjustments made

O.K.

Repairs desirable

(See separate sheet)

Please tick Service required:

A —

B —

C —

For intervals see overleaf

MAINTENANCE NOTES:

"Inspect" means check for correct operation or condition — if wrong, advise before carrying out repairs or adjustments at extra time.

"Check" means test and adjust/fill or tighten as necessary.

excel	esprit	A	B	C		excel	esprit	A	B	C	
●	●	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	Install protective covers	●	●	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	Check security of all fuel system connections
●	●	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	Renew engine oil and filter	●	●	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	Check throttle/kickdown/cruise control cable adjustment
●		<input type="checkbox"/>			Check manual gearbox oil, inspect for leaks	●	●	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	Check/adjust idle speed & CO level
●		<input type="checkbox"/>			Check auto. trans. fluid level, inspect for leaks	●	●	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	Inspect operation/condition of cooling fans
	●	<input type="checkbox"/>			Prior '88 M.Y.: Check g/box oil, inspect for leaks	●	●	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	Inspect exhaust system condition, mountings and joints
	●	<input type="checkbox"/>			'88 M.Y. on: Check g/box oil, inspect for leaks	●	●	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	Check brake fluid level
	●	<input type="checkbox"/>			Renew manual gearbox oil, inspect for leaks	●	●	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	Renew brake fluid & check seals
	●	<input type="checkbox"/>			Renew auto. trans. fluid and clean filter, inspect for leaks.						48,000 mls intervals
	●	<input type="checkbox"/>			Prior '88 M.Y.: Renew g/box oil, inspect for leaks	●	●	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	Renew all brake system rubber parts & hoses
	●	<input type="checkbox"/>			'88 M.Y. on: Renew g/box oil, inspect for leaks	●	●	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	Inspect brake system for leaks & damage
	●	<input type="checkbox"/>			Check final drive oil, inspect for leaks	●	●	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	Inspect pads & linings for wear
	●	<input type="checkbox"/>			Renew final drive oil, inspect for leaks	●	●	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	Check adjustment of handbrake
	●	<input type="checkbox"/>			Lubricate propshaft universal joints	●	●	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	Inspect brakes tell tale
	●	<input type="checkbox"/>			Lubricate speedo angle drive	●	●	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	Check/adjust clutch
	●	<input type="checkbox"/>			Oil front trunnions (if applicable)	●	●	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	Inspect for clutch fluid leaks
	●	<input type="checkbox"/>			Check P.A.S. fluid level	●	●	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	Check steering U/J clamp tightness
	●	<input type="checkbox"/>			Inspect P.A.S. for leaks & damage	●	●	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	Inspect condition of steering joints and gaiters
	●	<input type="checkbox"/>			Lubricate handbrake linkage	●	●	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	Renew trunion bushes (if applicable)
	●	<input type="checkbox"/>			Lubricate locks, hinges & catches	●	●	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	Inspect condition of all suspension bushes
	●	<input type="checkbox"/>			Lubricate throttle linkage & other controls	●	●	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	Check security of front & rear suspension
	●	<input type="checkbox"/>			Lubricate headlamp pivots	●	●	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	Inspect dampers for leaks & performance
	●	<input type="checkbox"/>			Check coolant level and strength	●	●	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	Check/adjust front hubs
	●	<input type="checkbox"/>			Inspect cooling system for leaks/damage	●	●	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	Check condition front hub bearings & seals.
	●	<input type="checkbox"/>			Inspect engine mounting rubbers	●	●	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	Repack grease
	●	<input type="checkbox"/>			Check/adjust cam-belt. Inspect valve timing	●	●	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	Inspect tyre condition, set pressures (incl. spare)
	●	<input type="checkbox"/>			Renew cam-belt	●	●	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	Inspect road wheel balance
	●	<input type="checkbox"/>			Inspect cam-belt tensioner	●	●	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	Check/tighten wheel nuts to spec. torque
	●	<input type="checkbox"/>			Check/adjust V-belts condition & tension	●	●	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	Inspect front & rear wheel toe-in
	●	<input type="checkbox"/>			Renew all V-belts	●	●	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	Check security of propshaft bolts
	●	<input type="checkbox"/>			Renew spark plugs	●	●	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	Check battery (except 'maintenance free')
	●	<input type="checkbox"/>			Check/adjust ignition timing & advance	●	●	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	Remove battery leads, clean & inhibit
	●	<input type="checkbox"/>			Check engine ancillaries for security	●	●	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	Clean Electric aerial
	●	<input type="checkbox"/>			Inspect valve clearances (extra time to adjust)	●	●	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	Check engine bay earth leads
	●	<input type="checkbox"/>			Renew air cleaner element	●	●	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	Inspect operation of all lights
	●	<input type="checkbox"/>			Renew fuel filter (Nat. Aspirated models)	●	●	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	Check/adjust headlamps
	●	<input type="checkbox"/>			36,000 mls intervals	●	●	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	Inspect operation of all electrics
	●	<input type="checkbox"/>			Renew fuel filter (Turbocharged models)	●	●	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	Inspect operation of A.C.U.
	●	<input type="checkbox"/>			Check fuel connections to carburettors	●	●	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	Top up screen wash reservoir
						●	●	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	Check/adjust door lock strikers
						●	●	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	Inspect seat belts condition & operation
						●	●	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	Clean all drain holes, check drains
						●	●	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	Check security of major unit mountings

Work completed by



Road Test Performance

- Engine performance
- Clutch operation
- Gearbox operation/noise
- Drive line noise/vibration
- Suspension noises
- Brake performance
- Wheel balance
- Steering performance
- Turbo boost pressure
- Light operation

Work completed by

<p>A SERVICE</p> <p>At 6,000 mls./10,000 km. or 6 months from registration (whichever sooner)</p>
<p>B SERVICE</p> <p>At 12,000 mls./20,000 km. or 6 months from last service (whichever sooner)</p>
<p>A SERVICE</p> <p>At 18,000 mls./30,000 km. or 6 months from last service (whichever sooner)</p>
<p>C SERVICE</p> <p>At 24,000 mls./40,000 km. or 6 months from last service (whichever sooner)</p>
<p>A SERVICE</p> <p>At 30,000 mls./50,000 km. or 6 months from last service (whichever sooner)</p>
<p>B SERVICE</p> <p>At 36,000 mls./60,000 km. or 6 months from last service (whichever sooner)</p>
<p>A SERVICE</p> <p>At 42,000 mls./70,000 km. or 6 months from last service (whichever sooner)</p>
<p>C SERVICE</p> <p>At 48,000 mls./80,000 km. or 6 months from last service (whichever sooner)</p>

<p>A SERVICE</p> <p>At 54,000 mls./90,000 km. or 6 months from last service (whichever sooner)</p>
<p>B SERVICE</p> <p>At 60,000 mls./100,000 km. or 6 months from last service (whichever sooner)</p>
<p>A SERVICE</p> <p>At 66,000 mls./110,000 km. or 6 months from last service (whichever sooner)</p>
<p>C SERVICE</p> <p>At 72,000 mls./120,000 km. or 6 months from last service (whichever sooner)</p>
<p>A SERVICE</p> <p>At 78,000 mls./130,000 km. or 6 months from last service (whichever sooner)</p>
<p>B SERVICE</p> <p>At 84,000 mls./140,000 km. or 6 months from last service (whichever sooner)</p>
<p>A SERVICE</p> <p>At 90,000 mls./150,000 km. or 6 months from last service (whichever sooner)</p>
<p>C SERVICE</p> <p>At 96,000 mls./160,000 km. or 6 months from last service (whichever sooner)</p>